

<b>DTC</b>	<b>P0705</b>	<b>Transmission Range Sensor Circuit Malfunction (PRNDL Input)</b>
------------	--------------	--


<b>DTC</b>	<b>P0850</b>	<b>Park/Neutral Switch Input Circuit</b>
------------	--------------	--

## CIRCUIT DESCRIPTION

The park/neutral position switch detects the shift lever position and sends signals to the ECM.


DTC No.	DTC Detection Condition	Trouble Area
P0705	2 or more switches are ON simultaneously at R, N, D, 2 and L positions (2-trip detection logic)	<ul style="list-style-type: none"> <li>• Short in park/neutral position switch circuit</li> <li>• Park/neutral position switch</li> <li>• ECM</li> </ul>
P0850	Park/neutral position switch remains ON while driving under conditions (a) and (b) for 30 sec. (2-trip detection logic) (a) Vehicle speed: 70 km/h (44 mph) or more (b) Engine speed: 1,500 – 2,500 rpm	

# WIRING DIAGRAM



Y

D11915



Y

D13177

# INSPECTION PROCEDURE

<b>1</b>	<b>Read PNP, REVERSE, DRIVE, 2ND and LOW signals.</b>
----------	---

**When using hand-held tester**

**PREPARATION:**

- (a) Remove the DLC3 cover.
- (b) Connect a hand-held tester to the DLC3.
- (c) Turn the ignition switch ON and hand-held tester main switch ON.

**CHECK:**

Shift lever into the P, R, N, 2 and L positions, and read the PNP, REVERSE, 2ND and LOW signals on the hand-held tester.

**OK:**

Shift position	Signal
2	2ND OFF → ON
L	LOW OFF → ON
R	REVERSE OFF → ON
P, N	PNP OFF → ON

**When not using hand-held tester**

**PREPARATION:**

Turn the ignition switch ON.

**CHECK:**

Measure voltage between terminals NSW, 2, L and R of ECM and body ground when the shift lever is shifted to the following positions.


**OK:**

Position	NSW–Body ground	R–Body ground	2–Body ground	L–Body ground
P,N	0 V	0 V	0 V	0 V
R	7.5 – 14 V*	7.5 – 14 V*	0 V	0 V
D	7.5 – 14 V	0 V	0 V	0 V
2	7.5 – 14 V	0 V	7.5 – 14 V	0 V
L	7.5 – 14 V	0 V	0 V	7.5 – 14 V

**HINT:**


\*: The voltage will drop slightly due to lighting up of the back up light.

<b>OK</b>	<b>Check and replace the ECM (See page IN-28).</b>
-----------	--



NG

## 2 Check park/neutral position switch.



### PREPARATION:

Remove the park/neutral position switch.

### CHECK:

Check the continuity between the switch terminals when operating the switch lever, as shown in the table below.

### OK:

Switch Position	Terminal No.	Specified Condition
R	6-3	Continuity
Except R		No continuity
D	7-3	Continuity
Except D		No continuity
2	4-3	Continuity
Except 2		No continuity
L	8-3	Continuity
Except L		No continuity
P and N	9-6	Continuity
Except P and N		No continuity

**NG**

Replace park/neutral position switch  
(See page [AT-9](#)).

**OK**

## 3 Check harness and connector between ECM and park/neutral position switch.

**NG**

Repair or replace harness and connector.

**OK**

Check and replace the ECM  
(See page [IN-28](#)).