



INSPECTION

INSPECT LOWER BALL JOINT FOR ROTATION CONDITION

- (a) As shown in the illustration, flip the ball joint stud back and forth 5 times before installing the nut.
- (b) Using a torque wrench, turn the nut continuously 1 turn each 2 – 4 seconds and take the torque reading on the 5th turn.

Turning torque:

0.1 – 3.45 N·m (1 – 35 kgf·cm, 0.8 – 30 in.-lbf)