BR04P-03

INSTALLATION

Installation is in the reverse order of removal (See page BR-10). HINT:

- Before installation, adjust the length of the brake booster push rod (See page BR-10).
- After installation, fill the brake reservoir with brake fluid, bleed brake system (See page BR-4) and check for leaks.
- Check and adjust the brake pedal (See page BR-6).

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 2077