INSTALLATION

2003 TOYOTA TACOMA (RM1002U)

BR053-02

Installation is in the reverse order of removal (See page BR-29).

HINT

After installation, fill the brake reservoir with brake fluid, bleed brake system (See page BR-4) and check for leaks.