RS028-03

INSTALLATION

HINT:

For step 1 to 6, refer to page SR-21.

- 1. INSTALL SPIRAL CABLE
- 2. INSTALL UPPER AND LOWER COLUMN COVERS
- 3. INSTALL STEERING WHEEL
- 4. INSTALL STEERING WHEEL PAD

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 2241