INSTALLATION

SA0BM-03

Installation is in the reverse order of removal (See page SA-143).

HINT:

After installation, fill the differential with hypoid gear oil (See page SA-137).

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 2006