

REMOVAL

REMOVE FRONT SEAT

(a) Using a screwdriver, remove the 2 seat track covers.

HINT:

Tape the screwdriver tip before use.

(b) Remove the 4 bolts and front seat.

NOTICE:

Be careful not to damage the body.