

# CIRCUIT INSPECTION

<b>DTC</b>	<b>P0500</b>	<b>Vehicle Speed Sensor "A"</b>
------------	--------------	---------------------------------

See page 3RZ-FE [DI-167](#), 5VZ-FE [DI-378](#).