


























ENGINE MECHANICAL (2RZ-FE, 3RZ-FE)














SST (Special Service Tools)

PP07D-05

| | | |
|---|--|--------------------------|
|  | 09032-00100 Oil Pan Seal Cutter | |
|  | 09201-10000 Valve Guide Bushing Remover & Replacer Set | |
|  | (09201-01060) Valve Guide Bushing Remover & Replacer 6 | |
|  | 09202-70020 Valve Spring Compressor | |
|  | (09202-00010) Attachment | |
|  | 09207-76010 Rocker Arm Bushing | |
|  | 09213-54015 Crankshaft Pulley Holding Tool | |
|  | 09223-15030 Oil Seal & Bearing Replacer | Crankshaft rear oil seal |
|  | 09236-00101 Water Pump Overhaul Tool Set | |
|  | (09236-15010) Bearing Stay | Valve stem oil seal |
|  | 09248-55040 Valve Clearance Adjust Tool Set | |
|  | (09248-05410) Valve Lifter Press | |

PREPARATION - ENGINE MECHANICAL (2RZ-FE, 3RZ-FE)

| | | |
|---|---|-------------------------------|
|  | <p>(09248-05420) Valve Lifter Stopper</p> | |
|  | <p>09330-00021 Companion Flange Holding Tool</p> | <p>Crankshaft pulley</p> |
|  | <p>09636-20010 Upper Ball Joint Dust Cover Replacer</p> | <p>Crankshaft timing gear</p> |
|  | <p>09816-30010 Oil Pressure Switch Socket</p> | <p>Knock sensor</p> |
|  | <p>09843-18040 Diagnosis Check Wire</p> | |
|  | <p>09950-40011 Puller B Set</p> | <p>Crankshaft timing gear</p> |
|  | <p>(09951-04010) Hanger 150</p> | |
|  | <p>(09952-04010) Slide Arm</p> | |
|  | <p>(09953-04010) Center Bolt 100</p> | |
|  | <p>(09954-04010) Arm 25</p> | |
|  | <p>(09955-04061) Claw No.6</p> | |
|  | <p>09950-50013 Puller C Set</p> | |
|  | <p>(09951-05010) Hanger 150</p> | |

| | | |
|---|--|---|
|  | (09952-05010) Slide Arm | |
|  | (09953-05010) Center Bolt 100 | |
|  | (09954-05021) Claw No.2 | |
|  | 09950-60010 Replacer Set | Spark plug tube gasket |
|  | (09951-00260) Replacer 26 | |
|  | (09951-00490) Replacer 49 | |
|  | (09952-06010) Adapter | |
|  | 09950-70010 Handle Set | |
|  | (09951-07150) Handle 150 | Valve guide bushing Spark plug tube gasket Crankshaft rear oil seal |
|  | 09960-10010 Variable Pin Wrench Set | |
|  | (09962-01000) Variable Pin Wrench Arm Assy | |
|  | (09963-00500) Pin 5 | Exhaust camshaft sub-gear |
|  | (09963-01000) Pin 10 | PS pump pulley |