REASSEMBLY

ST0HZ-01

Reassembly is in the reverse order of disassembly (See page ST-5).

HINT:

Use high-temperature grease to lubricate the bearings, gears, return spring and steel ball when assembling the starter.

2003 TOYOTA TACOMA (RM1002U)

Author: Date: 1557